

Instructions for Assembly / Montageanleitung

Changing filter elements on pressure / high-pressure filters

After changing the filter element, when refitting filters with an O-ring (3) on the filter housing (2), it is essential to observe the following:

- 1 Screw the filter housing (2) into the filter head until it stops.
- 2 Then unscrew the filter housing (2) again $\frac{1}{6}$ of a turn (60°).

The perfect functioning of ARGO-HYTOS filters and the outstanding characteristics of the filter elements are only guaranteed if original ARGO-HYTOS parts are used.

Filterelementwechsel an Druck- / Hochdruckfiltern

Nach Filterelementwechsel bei Wiedermontage von Filtern mit O-Ring (3) am Filtergehäuse (2) unbedingt beachten:

- 1 Filtergehäuse (2) bis auf Anschlag in den Filterkopf (1) einschrauben.
- 2 Filtergehäuse (2) wieder $\frac{1}{6}$ Umdrehung herausschrauben.

Die einwandfreie Funktion der ARGO-HYTOS Filter sowie die herausragenden Eigenschaften der Filterelemente sind nur bei Verwendung von Original ARGO-HYTOS Ersatzteilen garantiert.

Filter head (1)
Filterkopf (1)

Filter element
Filterelement

O-ring (3)
O-Ring (3)

Filter housing (2)
Filtergehäuse (2)

